

**Armstrong 114 Media Instructions**  
Media & Technology Support Services

This system is operated with the Touch Screen controller on top of the desk.

1. To turn the system on, touch the screen. You will be asked if you want to use the system in Presentation Mode (Standard Projector), Smart Board mode, or dual mode.
2. Once the system has warmed up, you will see a list of sources on the touch screen. Touch the button and the corresponding source will be sent to the projector and the speakers.
3. When you are using both screens simultaneously, you will see one source list on the screen for each projector. You must select the source for each screen individually. Sound will automatically be the last source you picked, and near the volume bar you will see a label telling you what source is going to the speakers.
4. You may connect your laptop to the system using the supplied HDMI cable.
5. This system has an AppleTV installed in it. You may use it to connect your iOS or Mac device to the system using AirPlay. Select the AppleTV source on the touch screen, make sure your device has WiFi and Bluetooth enabled, and follow the instructions that appear on the projector to connect.

**IT Help Desk: x2660**

**[mtss.tcnj.edu](http://mtss.tcnj.edu)**