

Multimedia Instructions

Media & Technology Support Services

This system is operated with the Touch Screen controller on top of the desk.

1. To turn the system on, touch the screen. You will be asked if you want to use the system in single projector mode or dual mode.
2. Once the system has warmed up, you will see a list of sources on the touch screen. Touch the button and the corresponding source will be sent to the projector and the speakers.
3. When you are using both screens simultaneously, you will see one source list on the screen for each projector. You must select the source for each screen individually. Sound will automatically be the last source you picked, and near the volume bar you will see a label telling you what source is going to the speakers.

Note: If the computer is powered off, when it is turned back on it may take a few minutes to appear on the monitor on the desk. If you are concerned the computer is not working, please turn the projection system on in "Dual" Mode and you should see the computers initial start-up sequence on Projector #2

IT Help Desk: x2660

mtss.tcnj.edu